

MEDEK

High Speed Hair Dryer

Model: MDHAIRF1



PARAMETERS

Product name: High speed hair dryer

Product model: MDHAIRF1

Voltage: 220-240V~

Frequency: 50-60Hz

Power : 1600-1800W

Off mode: 0.0 W

Standby mode: N/A

This equipment power management function is inappropriate as for the intended use



SAFETY INSTRUCTIONS

This appliance can be used by children aged 8 years and over and by persons with impaired physical, sensory or mental abilities or lack of experience and knowledge, provided that they have been supervised or instructed in the safe use of the appliance and understand the risks involved. Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision. If the cord is damaged, it must be replaced by the manufacturer, its after-sales service or by qualified persons to prevent any hazards.

When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off. For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

DESCRIPTION



- Ⓐ Handle
- Ⓑ Magnetic ring
- Ⓒ Indicator light
- Ⓓ Temperature control button
- Ⓔ Power switch / Speed button
- Ⓕ Magnetic inner filter
- Ⓖ Magnetic nozzle

WARNING:



Do not use this device in a bathtub, shower, or water-filled reservoir.

WARNING : Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

Regarding the precautions during user maintenance, please refer to the following section.

IMPORTANT WARNINGS

Before using this appliance, please read the following instructions carefully:

1. Do not use the appliance in wet conditions or with wet hands. Avoid immersing the appliance in water or any other liquid.
2. Unplug the appliance immediately after use to prevent hazards caused by exposure to water or damp environments. Avoid using the appliance in bathrooms or highly humid areas.
3. The following conditions prohibit the use of this electrical appliance:
 - . The power cord is damaged.
 - . The casing, accessories, or other parts show visible signs of damage.
 - . The appliance has come into contact with liquids.

4. Keep the appliance and its power cord away from heat-sensitive surfaces (e.g., flammable plastics, alcohol, etc.) and heat sources.
5. Do not pull the power cord forcefully. Avoid holding the appliance by its cord. After use, do not let the cord touch hot surfaces. Do not wrap the power cord around the appliance or twist the power cord to avoid circuit breakage or short circuit, which will burn out and make it unusable and endanger the safety of the user.
6. Unplug the appliance when not in use.
7. The back cover of this appliance can be removed for cleaning. Always disconnect the appliance from the power outlet and allow it to cool before cleaning. Do not use corrosive cleaners (e.g., those containing phenols).
8. Keep the appliance in good condition. Check that the moving parts are not misaligned or jammed and make sure there are no broken parts or anomalies that may prevent the appliance from operating correctly.
9. Do not use the appliance to dry pets or animals.
10. Do not use the appliance to dry textiles of any kind.

INSTRUCTIONS FOR USE

Make sure your hands are dry before connecting the power supply to the product.

Power switch/ Speed button: The power switch has three levels. Pulling it down to the extreme is for power off, pulling it up by one level to the middle is to enable power and low air speed, pulling it up by two levels to the top is the high air speed, and pulling it down to the extreme is for power off.

Temperature button: In the working state, press this button, and the temperature will be (in turn): cold air, warm air, hot air, hot and cold alternating air , in this cycle in turn.

Indicator status: Press the temperature key to switch between four levels of temperature. When cold air is selected, the blue light is on; when warm air is selected, the yellow light is on; when hot air is selected, the red light is on; when hot and cold alternating air is selected, the light color alternates between blue and red.

In the state of wind speed 1 or 2, long press the temperature control button for 5 seconds, the green light is on, and then long press for 5 seconds to enter the high frequency mode, and the green light is off . Click the temperature control button or push power switch button to power off to exit the high frequency mode , high frequency mode will run 30 minutes and automatically change back to last mode (the outlet temperature will be very high when using the high frequency mode, Be careful ,Please do not use this mode for normal use)

Note: When using this product, keep your hair away from the air net cover to prevent it from being sucked into the wind blade. Ensure that your hair is at least 3 cm away from the air outlet to avoid the risk of burning your hair.


NEGATIVE ION FUNCTION

This device has negative ions function, Negative ions can enhance hair hydration.

Under normal circumstances, the surface of the scalp appears in a scattered fish-scale pattern. Negative ions help to smooth out this pattern, making the hair look more lustrous. They also neutralize static electricity between strands, preventing split ends.

ACCESSORY OF MACHINE

Bring it close to the air outlet until it is securely attached through the magnetic ring.



Magnetic nozzle

MAINTENANCE AND CLEANING

Unplug the product when you do not intend to use it for an extended period of time to prolong its shelf-life.

Allow the device to cool down prior to storage. Ensure that the device is unplugged prior to cleaning it. This device may only be cleaned with a damp cloth, and chemical products must never be used for the same. To store the appliance, wind the power cord loosely just as it was in the original packaging. Do not tie the cord around the appliance. Clean the air inlet's grill periodically with the help of a soft brush. The air inlet's grill is fixed with magnetic adsorption for easy cleaning. Avoid dirt to get accumulated, thus prolonging the life of your hair dryer.

RECYCLING AND DISPOSAL



This marking indicates that this product should not be disposed with other household wastes throughout the EU.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



The device complies with the European Directives 2014/35/EU and 2014/30/EU.

Importer: Medek France

ADD: 05 rue de Rouen 94700 maisons ALFORT France

MADE IN CHINA