

MEDEK

INSTRUCTION MANUAL

MINI OIL HEATER



Please note:

This product is only suitable for well insulated spaces or occasional use.

Models covered by this instruction sheet:

MEDYL812 : 220-240V~, 50-60Hz 500W


IMPORTANT Read these instructions fully before using the heater. Retain these instructions for future reference.

NOTE:- THESE HEATERS ARE INTENDED FOR DOMESTIC USE ONLY

ASSEMBLY OF THE HEATER

Fit the separate foot to the radiator by pushing it firmly onto the control panel and end fin as shown in the diagram. Check the stability of the heater by standing it on a smooth level surface.

Fitting the foot to the Heater(Refer to the right fig.)



Parts

1. Power Switch
2. Thermostat Knob
3. Handle
4. Oil Filled Fins
5. Separate Foot

SAFETY INSTRUCTIONS (to be read before operating the heater)

1. Children of less than 3 years should be kept away unless continuously supervised. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
2. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
3. The product is for household use only.
4. Connect the appliance to single phase AC supply of the voltage specified on the rating plate.
5. **WARNING:** In order to avoid overheating, do not cover the heater.



Do not cover

6. Never leave the heater unattended while it is in use. Always turn the product to the OFF position and unplug it from the electrical outlet when not in use.
7. Extreme caution is necessary when any heater is used by or near children, invalids or elderly person and whenever the heater is left operating and unattended.
8. The heater must not be located immediately below an electrical socket-outlet.
9. Do not run cord under carpeting and do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area and where it will not be tripped over.
10. Do not use this heater if it has been dropped. Do not use if there are visible signs of damage to the heater. Use this heater on a horizontal and stable surface, or fix it to the wall, as applicable.
11. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person to avoid a hazard.
12. Avoid the use of an extension cord as this may overheat and cause a risk of fire.

13. Use the heater in a well-ventilated area. Do not insert or allow objects to enter any ventilation or exhaust opening. To prevent a possible fire, do not block air intakes or exhaust openings in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked. Use the heater on flat, dry surfaces only.
14. Do not place this heater near flammable materials, surfaces or substances, as there may be a risk of fire. Keep the above flammable materials, surfaces or substances at least 1m from the front of the product and keep them away from the sides and rear.
15. Do not use the heater in any areas where petrol, paint or other flammable liquids are stored e.g. Garages or workshops as a hot, arcing or sparking parts inside the heater.
16. Don't use this heater in the immediate surroundings of a bath, a shower or a swimming pool. Never locate the heater where it may fall into bathtub or other water container.
17. This heater is hot when in use. To avoid burns and personal injury, do not let bare skin touch hot surfaces. If provided, use handles when moving the product.
18. Be sure that no other appliances are in use on the same electrical circuit as your product as an overload can occur.
19. This heater is filled with a precise quantity of special oil.
20. Repair requiring opening of the oil container are only to be made by the manufacturer or his service agent who should be contacted if there is an oil leakage.
21. Regulations concerning the disposal of oil when scrapping the appliance have to be followed.
22. The heater should not be used in a room, of which the floor area is less than 5 M².
23. The cord shouldn't be placed nearby the hot surface of the appliance.
24. NOTE: It is normal when the heaters are turned on for the first time or when they are turned on after having not been used for a long period of time the heaters may have noise inside, This will disappear when the heater has been on a short while.

WARNING: Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

WARNING: To reduce the risk of fire, keep textiles, curtains, or any other flammable material a minimum distance of 1 m from the air outlet.

CAUTION — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.

OPERATION OF THE HEATER

NOTE 1:- When the heater is turned on for the first time or after having not been used for a long period, it may emit some smell and fumes. These will disappear when the heater has been on a short while.

- 1) Choose a suitable location for the heater, taking into account the safety instructions above.
- 2) Insert the plug of the heater into a suitable socket.
- 3) Turn the thermostat knob fully in a clockwise direction to the maximum setting.
- 4) When the desired room temperature has been reached, the thermostat knob should be turned slowly anti-clockwise until the thermostat is heard to click off and the light on the power switch is seen to go out. After this the heater will keep the air temperature in the room at the set temperature by switching on and off automatically.

CLEANING THE HEATER

- 1) Always un-plug the heater from the wall socket and allow it to cool down before cleaning.
- 2) Clean the outside of the heater by wiping with a damp cloth and buff with a dry cloth. Do not use any detergents or abrasives and do not allow any water to enter the heater.

MAINTENANCE

1. Always remove the plug from the socket-outlet and allow the radiator to cool down before clean the heater.
2. Wipe radiator with a soft damp (not wet) cloth.

WARNING:

Do not immerse the heater in water.

Do not use any cleaning chemicals such as detergents and abrasives.

Do not allow the interior to get wet as this could create a hazard.

3. In case of malfunction or doubt, do not try to repair the radiator yourself, it may result in a fire hazard or electric shock.

Contact details	MEDEK FRANCE maisons ALFORT France				
Model identifier(s): MEDYL812					
Item	Symbol	Value	Unit	Item	Unit
Heat output				Type of heat input, for electric storage local space heaters only (select one)	
Nominal heat output	P_{nom}	0,5	kW	manual heat charge control, with integrated thermostat	No
Minimum heat output (indicative)	P_{min}	0,5	kW	manual heat charge control with room and/or outdoor temperature feedback	No
Maximum continuous heat output	$P_{max,c}$	0,5	kW	electronic heat charge control with room and/or outdoor temperature feedback	No
Power consumption				fan assisted heat output	No
In off mode	P_o	0	W	Type of heat output/room temperature control (select one)	
In standby mode	P_{sm}	-	W	single stage heat output and no room temperature control	No
In idle mode	P_{idle}	-	W	Two or more manual stages, no room temperature control	No
In network standby	P_{nom}	-	W	with mechanic thermostat room temperature control	Yes
Standby mode with display of information or status			No	with electronic room temperature control	No
Seasonal space heating energy efficiency in active mode	$\eta_{s,on}$	85,0	%	electronic room temperature control plus day timer	No
				electronic room temperature control plus week timer	No
				Other control options (multiple selections possible)	
				room temperature control, with presence detection	No
				room temperature control, with open window detection	No
				distance control option	No
				adaptive start control	No
				working time limitation	No
				black bulb sensor	No
				Self-learning functionality	No
				Control accuracy	No
Remark: 'This product is only suitable for well insulated spaces or occasional use.' will be showed on the cover page of the user manual, free-access websites of manufacturer, product packaging.					

CONFORMITY WITH DIRECTIVES



 This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



The device complies with the European Directives 2014/35/EU and 2014/30/EU.

Medek France

94700 maisons ALFORT France

MADE IN CHINA