




Instruction Manual



Stand Blender

Model no:MEPALB606

AC 220-240V 50-60Hz 600W



Before use, please watch this video carefully

PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE

IMPORTANT SAFEGUARDS

When using this electrical appliance, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Before using check that the voltage indicated on the product corresponds with the voltage of your electrical outlet.
3. Do not let cord hang on hot surface or over edge of table or counter.
4. Do not operate any appliance with a damaged cord or plug or after the appliance malfunction or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
5. If the supply cord is damaged , it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
6. Close supervision is necessary when any appliance is used by or near children.
7. Avoid contacting the moving parts while operation.
8. Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but must be used only when the blender is not running.
9. The use of attachments not recommended or sold by manufacturer may cause fire, electric shock or injury.
10. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning. To disconnect, turn any control to “off”, then remove plug from wall outlet by grasping the plug, not the cord.
11. To reduce the risk of injury, never place blade assembly on the motor unit / Main body without the jar properly attached.
12. This appliance shall not be used by children. Keep the appliance and its cord out of reach of children
13. Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved
14. Children should be supervised to ensure that they do not play with the appliance.
15. Do not leave the machine on unattended.
16. When removing the blender from the motor unit, wait until the blades have completely stopped.
17. Always operate blender with cover in place.
18. Always use the appliance on a secure, dry level surface.
19. Never place this appliance on or near a hot gas or an electric burner or where it could touch a heated appliance.
20. Do not use outdoors.
21. Do not use appliance for other than its intended use.
22. Be careful if hot liquid is poured into the blender as it can be ejected out of the appliance due to a sudden steaming
23. This appliance is intended to be used in household and similar applications

such as:


- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments.

WARNING: Potential injury from misuse. Care shall be taken when handling the sharp cutting blades, emptying the bowl and during cleaning.

CAUTION: Ensure that the blender is switched off before removing it from the stand. Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.

HOUSEHOLD USE ONLY

KNOW YOUR BLEANDER



How to use

1. Clean and cut the ingredients and put them into the jar. Close the lids and turn the lids by clockwise, place the measure cup exactly into the lid by aiming at a fixed position in the middle of the lid and turning the cup clockwise until tight. (See Fig.1)




Fig.1

2. Finally, place the assembled jar onto the the motor unit / Main body by adjust well the connector / tool test / tool test at the bottom of the jar, and tight it. (See Fig.2 & 3)




Fig 2






Fig 3



3. Adjust the connector / tool test at the bottom of the travel jar / juice cup, assemble the assembled travel jar / juice cup components, and tighten it to the locking mark position. (Fig4)




Fig 4

4. Rotate the knob to the corresponding speed level, the machine starts working.

5. Instructions

1. Peeled or cored the fruit or vegetables and then cut it into small dices.
2. Place the food to be blended into the jar (Fig 5) . Usually, certain amount of purified water has to be added to facilitate the smooth running of appliance. The proportion of the food and water is 2:3. The amount of mixture should not exceed the max level as indicated on the jar.

RECIPE


FOOD TYPE	SPEC	WEIGHT	SPEED	Remark
Carrot (apple, pear etc.)	Cut into 15mm*15mm*15mm	Carrot: 600g Water: 900g	High speed	Juice jar
Carrot (apple, pear etc.)	Cut into 15mm*15mm*15mm	Carrot: 240g Water: 360g	High speed	Juice cup

Note: never use boiling liquids or run the appliance empty.


3. Put the lid on the jar. Be sure the measuring cup is in place.
4. Plug the power cord into a standard wall outlet.
5. Turn the speed knob to the appropriate speed setting for your task.
6. For quick or delicate blending tasks, turn the speed knob to P position and hold for a few seconds and then release, the knob will reset to O position automatically. Operate several times until the consistence you want is obtained. If you want to add ingredients while the blender is working, remove the measuring cup and place through the lid opening. (Fig 6)
7. When the consistence you desire is obtained, turn the knob to O position.

Note: 1) For each use, the consecutive operation time should not exceed 1 minutes. At least 10 minutes rest time must be maintained between two continuous cycles, let the unit cool to room temperature before performing next operation cycle.

- 2) If you want to stop the machine during operation, turn the knob to O position anytime.



Before blending, add food to be blended into the jar.



During blending, add the ingredient through the lid opening.

Fig 5

Fig 6

Important operating tips

- For best circulation of food that is to be blended with some liquid, pour the liquid into the jar first, then add solids.
- Some of the tasks that cannot be performed efficiently with a blender are: beating egg whites, whipping cream, mashing potatoes, grinding meat, mixing dough, extracting juice from fruit and vegetable
- The following items should never be placed in the unit as they may cause damage: bones, large pieces of solid, frozen food, or tough foods.

CARE AND CLEANING

This product contains no user serviceable parts. Refer service to qualified service personnel.

1. Before cleaning, unplug the blender.
2. Always wash immediately after use for easier cleaning. Don't let food dry on the jar assembly and travel jar / juice cup as this will make cleaning difficult.
3. Pour a little warm soapy water into the jar and travel jar / juice cup for a few seconds. And then empty the jar and travel jar / juice cup.
4. Disassemble all detachable parts, remove the jar assembly and travel jar / juice cup assembly from the main unit, the jar holder cannot disassemble (Fig 7), it must clean together with the jar.




Fig 7

5. Rinse the measure cup, lid, seal ring, jar, travel jar / juice cup, tool rest and blade assembly by hands or in a dishwasher and then dry. They are dishwasher safe components, but the temperature setting shall not exceed 60°C.
6. Brush the blade clean using warm soapy water, then rinse thoroughly under the tap. Don't touch

the sharp blades, handle carefully. **Don't immerse the blade assembly in water.** Leave to dry upside down away from children.

7. Wipe the the motor unit / Main body surface with a damp cloth and dry thoroughly. Remove the stubborn spots by rubbing with non-abrasive cleaner. If liquids spill into the motor unit; first unplug the unit, then wipe with a dry cloth and dry thoroughly.

Warning

- 1) **Do not immerse the the motor unit / Main body in liquid to prevent the risk of electric shock.**
- 2) **Do not use rough scouring pads or cleansers on parts or finish.**
- 3) **Do not place engine base into dishwasher for cleaning. This unit is not available for dishwasher.**



■ This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



The device complies with the European Directives 2014/35/EU and 2014/30/EU.

This device complies with the requirements of European Commission Regulation (EU) 2023/826 on standby energy consumption

Power consumption in off mode	0.17W
Power consumption in standby mode	W
Maximum time required to automatically reach shutdown mode	min

Importer: **Medek France**

ADD:94700 maisons ALFORT France

MADE IN CHINA