




Tower air cooler



Instruction manual

MEDML129



Before use, please watch this video carefully

Components Diagram



CAUTION

1. Use as per the rating voltage.
2. Do not repair or remake the appliance by yourself, It should be repaired by the repairmen.
3. Do not operate the appliance with wet hands, in order to avoid damage.
4. If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agents.
5. When the appliance is not in use, switch it off and unplug it.
6. Do not insert things to air outlets and inlets, in order to avoid damage.
7. Do not use the appliance near explosive and combustible gas.
8. Use the appliance only on a flat surface.
9. Do not use outdoors.
10. The level of water tank should be not over "MAX" scale at any time, when humidifying, the total level of water tank should be "MIN" scale.
11. After adding water to the water tank, do not tilt or knock over the appliance when you put or move it. If you want to move, please drive it at side, in order to avoid spilling the water.
12. Do not turnover the appliance. If it is toppled over, and there have some water in the body, should unplug the power supply. Then send it to repair department or after-sales service and overhaul.
13. Do not put things on the appliance, do not cover air vent. **WARNING:** Do not cover heater, in order to avoid over heat.
14. Clean the appearance with a lightly damp cloth. Do not use any type of detergents or solutions. Do not rinse with water.
15. Do not make air outlets and inlets near the wall or curtain.
16. Do not knock or shake the body when use, otherwise it may cause stop.
17. The water in water tank can easily metamorphose and have at summer, renew the water frequently.
18. The appliance must not be located immediately below a socket outlet.
The rating current of socket should exceed 10A.
19. Do not use the appliance in the immediate surrounding of a bath, a shower or a swimming pool.
20. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Cleaning and user maintenance shall not be made by children without supervision.
21. Children should be supervised to ensure that they do not play with the appliance.
22. Do not use the appliance with a programmer, timer or any other device
That switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
23. Children should be supervised to ensure that they do not play with the appliance.
 - Be aware that high humidity levels may encourage the growth of biological organisms in the environment.
 - Do not permit the area around the humidifier to become damp or wet. If dampness occurs, turn the output of the humidifier down. If the humidifier output volume cannot be turned down, use the humidifier intermittently. Do not allow absorbent materials, such as

- carpeting, curtains, drapes, or tablecloths, to become damp.
- Unplug the appliance during filling and cleaning.
- Never leave water in the reservoir when the appliance is not in use.
- Empty and clean the humidifier before storage. Clean the humidifier before next use.


OPERATION

Take out the product from gift box

ASSEMBLING

Base installation instructions:

Turn the product upside down, take out the base, Angle the chassis to the buckle and fasten it (see Figure 1), align the product with the buckle, rotate the product and the base in the direction shown in the base installation diagram (see Figure 2), and lock the product until you hear the buckle sound (see Figure 3). To disassemble the base, please press the buckle (Figure 4).





Fill the water tank:

1. Pull the water tank out about 1/3 of the products.
2. Fill the water tank with cold and clean water. Make sure that water level is between “Min” minimum level and “Max” maximum level.
3. To increase the cool effect insert the ice box in the water tank. Before use ice box, they must be filled by water and put in the refrigerator until they are completely frozen.
4. Close the water tank.

Attention!

1. Make sure the product is unplugged from the mains before filling or refelling the water.
2. Only use water in the water tank. Do not add any chemicals ,oils or other additives.
3. Only use cold water in the water tank(previously boiled)
4. Make sure the water level in the water tank is between minimum level .(indicated by “Min”)and maximum level(indicated by “Max”)
5. Do not use pump ,when there is no water on the water tank.

Remote control and panel display:



- a. Humidification
- b. Timer
- c. Wind mode
- d. Speed
- e. Oscillation
- f. On / off

Place the unit on a firm level surface and plug it into a socket. Power indicator light reminding this products in standby mode. Turn on "⏻" button ,default setting is in middle speed, Turn it again, products in standby .

1. Speed key  : Press this key, automatically starting from mid ,high ,low

2. Mode key "  ",default setting is in normal wind. Press this key, automatically setting from normal wind-natural wind-sleep wind

3. Swing key  : press this key, The product begins to swing from right side to left side.

Press again to cancel the function

4. Timer key  : press this key, the timer max to 12H, each pressing 1hour.

5. Cooling key  : press this key, start this function, and if you add the freezing ice crystal box in the water tank, air blow out temperature will much more cooling. It cancels this function when you press again. (make sure water level is above min. line)

Note1:

When the water is insufficient, it is necessary to add an appropriate amount of water, and dry burning without water is strictly prohibited

Note2: If you want to turn on the cooling air function again after turning off the cooling air function, wait 30 seconds before turning on the cooling air function to prevent the water pump from not filling.


6. Light off function: after 10 minutes of work, the product automatically turn off all lights, press any key to light the screen.

Remote control:

1. Before using the remote control: first unplug the plastic sheet at the lower end of the remote control, and the transmitter at the front of the remote control must be aligned with the receiving window on the product (i.e. the position of the display panel).
- 2, avoid direct sunlight exposure to the receiving window, so as not to affect the effect of the receiver.
3. If the remote control is not used for a long time, please take out the battery and dispose of it properly.
4. All operation in Remote control same as product's control panel.

BATTERY

The remote control use one button cells, model No. CR2025 (3V). We recommend the use of Lithium type battery for longer use.



Note:

1. Please follow battery disposal instruction on battery packaging, or contact your local councils for safely disposal of batteries.
 2. Remote with battery.
- Batteries are to be inserted with the correct polarity

- Exhausted batteries are to be removed from the appliance and safely disposed of
- If the appliance is to be stored unused for a long period, the batteries should be removed
- The supply terminals are not to be short-circuited

ICE BOX METHOD

1. Before using, add water to the ICE BOX not more than MAX, put it into the refrigerating about 8 hours to make sure it cold. Two ICE BOX can use circularly.

Note: the ice box should be far way from children to avoid eating


2. If you need to use cool pack, put the cool pack inside the water tank before filling in water.
 3. When filling water, always check the water level indicator position, do not fill water lower than lowest water level indication line MIN, and do not fill water over the highest water level indication line MAX.

CLEANING AND MAINTENANCE


MAINTENANCE AND CLEANING

1. Always unplug the unit from mains power supply before attempting any cleaning or user maintenance.
2. The water tank must be drained of any water after each use. To do so, carefully pull the water tank out from the unit then hold a suitable vessel underneath to catch the water. Once the water tank has been drained, wipe away any excess water with a soft cloth.
3. Wipe the unit with soft, damp cloth and dry thoroughly.
4. Do not use flammable liquid, abrasive cleaning solvents, polishes or scouring pads to clean the humidifier, as this may cause damage.
5. Please ensure that the unit and all of its parts are cleaned regularly to reduce the risk of limescale and bacteria forming.
6. Attention: Must unplug the power plug when cleaning.
7. Don't make the water into the control panel.
8. Tip: When using the machine for a long time, it is recommended to clean it once a week.
9. Before cleaning, disconnect the power supply.
10. If this machine is not used for long time, clean, dry and pack this machine together with all components in the original packing, and store it in cool and dry environment.
11. Do not flush this machine directly with water. Clean this machine by soft cloth and neutral detergent. Do not use gasoline, toluene and other solvents for cleaning.
12. After cleaning, do not use this machine until it becomes dry completely.
13. If there is scale on the water tank and water pump, clean following diagram. Turn the knob of the water pump and appropriate amount of neutral detergent (such as dishwa into the water tank, wipe the water tank and water pump clean the water tank with clean water. After the water tan reinstall them into the product.

pump



Small rotary



TECHNICAL SPECIFICATION

- Rating power : 60W
- Power : 220-240V ~ 50Hz



- Class II

Part 1 :

Tower air cooler MEDML129			
Description	Symbol	Value	Unit
Sum of air delivery	F	26,08	m ³ /min
Absorbed power	P	39,9	W
Calculated Service Value	Sv	0,65	(m ³ /min)/W
Sound power level	LWA	6 2	dB(A)
Maximum air velocity	c	3,62	meters / sec
The seasonal electricity consumption	Q	19,5	KWh/a
Measurement standard for service value	IEC 60879:2019		
Contact for more information	Medek France		

	94700 maisons ALFORT France
--	-----------------------------

Part 2:

Product information for power consumption	
Standby mode consumption (P_{SB})	0,29W

PACKING LIST

Manual x 1 ; Remote control x 1; Screw accessories x ; Bottom x 1; Ice box x 2



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



Worn out and dead batteries must be discarded in specially marked containers, delivered to special waste collection points or to electronic equipment vendors.



The device complies with the European Directives 2014/35/EU and 2014/30/EU.

Medek France

94700 maisons ALFORT France

MADE IN CHINA

<http://www.medekfrance.com>