



Water Feeder



MODEL NO:MEDPETWATER



Before use,
please watch this video carefully

1. WARNING NOTES

*This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

*Children should be supervised to ensure that they do not play with this appliance. Cleaning and user maintenance shall not be made by children without supervision.

*This product shall only be powered by the safety extra-low voltage marked on the product nameplate. For charging, use a power bank with 5V/1A output and a measured maximum output power less than 15W.

*Charging reminder: The red indicator light flashes intermittently 5 times per minute, please charge the device.

*Water refilling reminder: The blue indicator light flashes intermittently 5 times per minute, please replenish drinking water.

*Charging in progress: The green indicator light flashes.

*The green indicator light flashes and turns off after 2 hours.

*Install and operate the device strictly in accordance with this user manual.

Use indoors only. Keep away from direct sunlight (which may impair device functions) and open flame sources.

*Although the device operates at low voltage, pets chewing the power cord may create electric leakage risks. Please guide proper usage.

*Place the device horizontally to prevent tipping, otherwise normal water output may be affected.

*To avoid being knocked over by pets, place the product against walls or corners. Do not place it on elevated surfaces to prevent damage to the unit or injury to pets from falls.

*The main unit must NOT be immersed in water or rinsed directly. Protect the water pump during routine cleaning. If dropped accidentally, internal components may break and cause product failure.

*Children may only use this device under

adult supervision.

- *Disassembly and repair by anyone other than professional maintenance personnel are prohibited to avoid accidental injury.

- *Use purified water or boiled water. Clean weekly to prevent limescale buildup.

- *The unit will shut down automatically when water is insufficient. Disconnect power before changing water.

- *This appliance contains batteries that are non-replaceable.

- *Align the control box with the water tank slot and assemble it in place. After proper assembly, the water tank and the control box are firmly fixed without any gap.

2. PACKING LIST

After unpacking the carton, check whether the product is intact and verify all accessories. Contact your dealer if any parts are missing or damaged!



Main Unit x 1



Control Module x 1



Water Pump x 1



User Manual x 1



Filter Cartridge x 1




Charging Cable x 1



Water Guide Tube x 1

(Note: Some accessories are stored inside the main unit water tank, please take them out for checking.)

3. Product Outline Structure & Component Names



Warm Reminder: All illustrations of the product and accessories in this manual are schematic diagrams for reference only. Due to product updates and upgrades, the actual product may be slightly different from the illustrations. Please take the actual product as standard.

4. Product Specifications

Suitable Pets	Cats / Small & Medium Dogs
Water Tank Capacity	2.5L
Rated Power	3W
Rated Voltage	3.7V
Charging Voltage	5VDC/1A
Lithium Battery Capacity	2000mAh
Material	ABS + PC
Net Weight	610g
Product Dimensions	200mm × 184mm × 170mm
Operating Temperature	1°C – 40°C

*All data are measured in Deli Laboratory. Slight deviations may occur due to changes in objective environmental conditions.

5. Operating Instructions

Item	Operation	Details
Button Operation Guide	Power On / Off	Press and hold the power button for 2 seconds. Induction mode is enabled by default upon startup.
	Mode Selection	hort press the power button
Power Control	Continuous Water Flow	The water pump runs continuously to discharge water (Available only when external power supply is connected).Indicator Prompt: Red light flashes 3 times, then turns off automatically.
	Timed Water Flow	After startup, the pump activates automatically for 2 minutes every hour.Indicator Prompt: Yellow light flashes 3 times, then turns off automatically.
	Sensor-activated Water Flow (Default Mode)	The pump starts to supply water once infrared sensor is triggered. Water stops 10 seconds after the sensing target leaves.Indicator Prompt: Blue light flashes 3 times, then turns off automatically.
Indicator Light Guide	Low Battery	Red light flashes 5 times intermittently per minute – Please charge the device
	Low Water Level	Blue light flashes 5 times intermittently per minute – Please add water
	Charging in Progress	Green light flashes
	Fully Charged	Green light stays steadily on

6.Cleaning Instructions

It is recommended to clean all components and completely replace the water every week, and replace the filter cartridge and pump filter cotton every month.

1.Before cleaning, press and hold the power button for 2 seconds to power off. If the charging port is connected to power, unplug the charging cable and cover the waterproof rubber plug of the charging port.

2.Remove the filter tray, rotate the water guide tube, and detach it from the bottom of the filter tray and the water pump.

3.Take out the filter cartridge, and remove the pump filter cotton from the water pump.

4.Thoroughly clean all components. The water storage tank, filter tray and drinking tray can be rinsed with water.

5.Clean the inner and outer walls of the water storage tank, then wipe off moisture on the outer wall.

6.After cleaning, insert both ends of the water guide tube into the interfaces of the filter tray and water pump. Ensure tight connection to prevent easy detachment, then reinstall other components in sequence.

7.Troubleshooting

1.Blue light flashes in standby mode

Insufficient water. Add water to above the water level line promptly.

Red light flashes in standby mode

2.Battery level < 15%, please charge the device. Long-term non-charging will cause complete battery over-discharge.

3.Green light does not turn on after connecting charging cable

① Check whether the charging cable and adapter work properly; replace them if defective.

② If the battery is over-discharged, wait 15 minutes after plugging in the power cord. The green light will light up automatically to enter charging mode.

4.Water fountain fails to work

① Press and hold the power button for 2 seconds to start up. If it cannot power on, charge for 2 hours and try again.

② Ensure the water level is above the minimum line, and check if the water guide tube is firmly connected.

③ Disassemble the water pump, clean the rotating shaft, inner wall and filter cotton to remove limescale and impurities.

5. The unit fails to activate when pets approach

Switch working modes: Blue light flashing = Sensor Mode (automatically activates when pets get close); Yellow light flashing = Timed Mode (no automatic triggering).

6. Turbid water / Foreign impurities in water

- ① Soak the new filter cartridge in clean water for 5 minutes and rinse before use.
- ② Rinse the filter cartridge weekly, replace the filter cartridge monthly, and clean the inner wall of the water fountain and water pump to keep the water clean and water passage unobstructed.

Statement on Restriction of Hazardous Substances in Electrical and Electronic Products



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



The device complies with the European Directives 2014/35/EU and 2014/30/EU.

Medek France
94700 maisons ALFORT France
MADE IN CHINA